



Siser EasySubli

Application Instructions

1. Create your design and add contour cut CropMarks
2. Load EasySubli Vinyl in your SG400 sublimation printer shiny side up (print on textured side)
3. Print your design (including contour cut marks) onto the EasySubli Vinyl – DO NOT MIRROR
4. Wait 20 minutes for ink to dry before touching (or place under open heat press to dry faster)
5. Contour cut your design on your cutter. (Optional – place vinyl on cutting mat / carrier sheet)
6. Weed away excess material.
7. Remove design from backer, or use transfer mask to lift multi-part designs
8. Place design face up on garment to be decorated
9. Cover with a non-stick sheet
10. Press at 310°F/154°C for 10-15 seconds at Medium pressure
11. If using transfer mask, you can peel the mask Hot

Applies to 100% Cotton, Poly-Cotton Blends, 100% Polyester

Wait 24 hours before first wash, Machine wash warm or cold / mild detergent. Do not dry clean

Application Instructions with multiple elements using Transfer Mask

In cases where your design has multiple elements, use of transfer mask is recommended.

1. Peel the white textured backer from the transparent mask
2. Hold the mask in a U-shape from the center, lay the mask down on top of your weeded design

3. Use a squeegee to get the transfer mask in solid contact with your design so it can be lifted
4. Peel the transfer mask and design from the backer on the EasySubli vinyl
5. Place the transfer mask and design on your garment so that the design is visible
6. Recommended to use a non-stick sheet even when using the transfer mask